

Communication Flow Key




Figure 1. System Architecture




FIGURE 1

Figure 2. SANMetrics Architecture




FIGURE 2

Figure 3

300

301 Analyzer - Channel 1A (1 Gb, 61A, Fibre Channel) Indicator 01 Analyzer - Channel 1B (1 Gb, 61A, Fibre Channel) Target bc: LUN 00 Target ef: LUN 00									
Description	Time Range	Source	Destination	Port	Type	Total Count	Severity	Category	Value
1. % of Arbitration Losses exceeds threshold	000:00:00:01:256:513	bc	ef	0.1	FC-2	1	1	Warning	515
2. Arbitration Loss by device	000:00:00:01:256:513	bc	ef	0.1	FC-2	377	5	Warning	
3. ARB FD while loop in closed state	000:00:00:01:227:250	N/A	N/A	0.1	FC-2	15	4	Warning	
4. Arbitration Loss by device	000:00:00:02:069:425	bc	ef	0.1	FC-2	377	5	Warning	
5. Arbitration Loss by device	000:00:00:02:083:538	bc	ef	0.1	FC-2	377	5	Warning	
6. Arbitration Loss by device	000:00:00:02:084:138	bc	ef	0.1	FC-2	377	5	Warning	
7. Arbitration Loss by device	000:00:00:02:088:550	bc	ef	0.1	FC-2	377	5	Warning	
8. Out of Credits during Tenancy	000:00:00:067:382:950	01	bc	0.1	FC-2	10	1	Warning	5
9. ARB FD while loop in closed state	000:00:00:085:940:988	N/A	N/A	0.1	FC-2	15	4	Warning	
10. ARB FD while loop in closed state	000:00:00:246:308:063	N/A	N/A	0.1	FC-2	15	4	Warning	
11. ARB FD while loop in closed state	000:00:00:262:744:350	N/A	N/A	0.1	FC-2	15	4	Warning	
12. ARB FD while loop in closed state	000:00:00:357:337:875	N/A	N/A	0.1	FC-2	15	4	Warning	
13. Failed Open: Open detected while loop in Open State	000:00:00:473:707:462	bc	bc	0.1	FC-2	1	2	Warning	
14. Out of Credits during Tenancy	000:00:00:504:365:163	01	bc	0.1	FC-2	10	1	Warning	5
15. Out of Credits during Tenancy	000:00:00:504:303:338	01	bc	0.1	FC-2	10	1	Warning	2
16. Out of Credits during Tenancy	000:00:01:134:042:583	01	bc	0.1	FC-2	10	1	Warning	4
17. Out of Credits during Tenancy	000:00:01:134:123:863	01	bc	0.1	FC-2	10	1	Warning	1
18. Out of Credits during Tenancy	000:00:01:671:187:088	01	bc	0.1	FC-2	10	1	Warning	6
19. Out of Credits during Tenancy	000:00:01:671:590:700	01	bc	0.1	FC-2	10	1	Warning	1
20. Out of Credits during Tenancy	000:00:02:729:551:288	01	bc	0.1	FC-2	10	1	Warning	5
21. Out of Credits during Tenancy	000:00:02:729:564:925	01	bc	0.1	FC-2	10	1	Warning	1
22. Out of Credits during Tenancy	000:00:03:257:330:838	01	bc	0.1	FC-2	10	1	Warning	4

Last: 000:00:00:264:025:275

Date/Time: 000:00:03:524:321:384

File: 000:00:00:000:001:912

For Help, Press F1


Figure 4

400

$\frac{402}{201}$

401

[illegible]







FIGURE 6



GTX-SANHEITICS - 2dhrnetund

File: 0000000000_001_512

Toplogy

Analyzer Channel 1A (1 Ob, 61A, Fine Channel)

Indicator 01

Analyzer Channel 1B (1 Ob, 61A, Fine Channel)

Target bc: LUN 00

Target d: LUN 00

Description	Frequency	Source	Destination	Pct	Type	Total Count	Severity	Category	Value	Value Description
Out of Credits during Tenancy	000.00.00.067.282.500	N/A	N/A	0.1	FC2	10	1	Warning	515	Times Out of Credit
Out of Credits during Tenancy	000.00.00.604.365.163	bc	bc	0.1	FC2	10	1	Warning	5	Times Out of Credit
Out of Credits during Tenancy	000.00.00.604.500.338	bc	bc	0.1	FC2	10	1	Warning	2	Times Out of Credit
Out of Credits during Tenancy	000.00.00.134.042.563	bc	bc	0.1	FC2	10	1	Warning	4	Times Out of Credit
Out of Credits during Tenancy	000.00.00.134.123.883	bc	bc	0.1	FC2	10	1	Warning	1	Times Out of Credit
Out of Credits during Tenancy	000.00.00.671.187.088	bc	bc	0.1	FC2	10	1	Warning	6	Times Out of Credit
Out of Credits during Tenancy	000.00.00.671.350.700	bc	bc	0.1	FC2	10	1	Warning	1	Times Out of Credit
Out of Credits during Tenancy	000.00.00.725.651.288	bc	bc	0.1	FC2	10	1	Warning	5	Times Out of Credit
Out of Credits during Tenancy	000.00.00.725.654.625	bc	bc	0.1	FC2	10	1	Warning	1	Times Out of Credit
Out of Credits during Tenancy	000.00.00.257.320.838	bc	bc	0.1	FC2	10	1	Warning	4	Times Out of Credit
Failed Open: Open detected while loop in Open State	000.00.00.018.227.250	N/A	N/A	0.1	FC2	15	4	Warning		
ABR FI while loop in closed state	000.00.00.095.940.988	N/A	N/A	0.1	FC2	15	4	Warning		
ABR FI while loop in closed state	000.00.00.246.398.063	N/A	N/A	0.1	FC2	15	4	Warning		
ABR FI while loop in closed state	000.00.00.282.214.350	N/A	N/A	0.1	FC2	15	4	Warning		
ABR FI while loop in closed state	000.00.00.367.597.875	N/A	N/A	0.1	FC2	15	4	Warning		
Adaptation lost by device	000.00.00.001.785.513	bc	bc	0.1	FC2	377	5	Warning		
Adaptation lost by device	000.00.00.022.093.425	bc	bc	0.1	FC2	377	5	Warning		
Adaptation lost by device	000.00.00.023.583.538	bc	bc	0.1	FC2	377	5	Warning		
Adaptation lost by device	000.00.00.027.093.138	bc	bc	0.1	FC2	377	5	Warning		
Adaptation lost by device	000.00.00.032.108.550	bc	bc	0.1	FC2	377	5	Warning		

File: 0000000000_001_512

Date: 000.00.00.284.621.951

Last: 000.00.00.284.621.951

File: 0000000000_001_512
Date: 000.00.00.284.621.951
Last: 000.00.00.284.621.951
GTX-SANHEITICS - 2dhrnetund
3:54 PM

ATTY DKT. NO.: FNSR/1001.05
U.S. SERIAL NO.: UNKNOWN CONF. NO.: UNKNOWN
FILED: HEREWITH
APPLICANT: FINISAR CORPORATION
TITLE: NETWORK ANALYSIS SAMPLE MANAGEMENT PROCESS
INVENTOR: KLOTZ, ET AL.
EXPRESS MAIL NO.: EV335470586US PAGE 9 OF 12




Figure 9




Figure 10




Figure 11




FIGURE 12